

# HOLT OF CALIFORNIA CERTIFIED USED EQUIPMENT

You know Holt of California delivers the quality you expect. Now you can have the same confidence in Holt of California Certified Used Equipment. Each lifttruck undergoes 105 quality assurance checks and features a standard 6-month/1,000-hour Powertrain Limited Warranty. You can rely on Holt of California Certified Used Equipment to deliver the productivity you need

## 105-POINT CERTIFICATION PROCESS

It's not easy for a forklift to measure up to the exacting standards of Caterpillar. In fact, there are more than 100 different quality assurance checks each forklift must meet before receiving certification from Holt of California. This thorough approach ensures total customer satisfaction with each truck.

## POWERTRAIN LIMITED WARRANTY

For even greater customer confidence, Holt of California's Powertrain Limited Warranty comes standard with every Certified Used forklift.

5 Years or Less Service: 12-Month/2,000 Hour  
7 Years or Less Service: 6-Month/1,000 Hour

## 30-DAY/150-HOUR COMPONENT WARRANTY

In addition to the Powertrain Limited Warranty, all Certified Used forklifts come standard with a 30-day/150-hour Component Warranty.

## CERTIFIED USED EQUIPMENT POWERTRAIN LIMITED WARRANTY

### Internal Combustion Powered Industrial Truck Coverage

- \* Engine (excluding all accessories)
- \* Powershift and standard transmission
- \* Differential
- \* Drive Axle (excluding brake shoes)

### Battery Powered Industrial Truck Coverage

- \* Drive motor (excluding brushes)
- \* Electronic (SCR/transistor) control panel components
- \* Contactor panels (excluding contact tips and switches)
- \* Differential
- \* Drive axles (excluding brake shoes)

Eligible forklifts include all sit-down forklifts with up to 20,000-lb. lifting capacities. Holt of California Certified Used Equipment has 5 years or less service or under 10,000 hours of service.



## Certification Check Sheet

This Certification Check Sheet must be 1) completed with all items checked, 2) signed by person(s) performing and inspecting both mechanical and appearance items, and 3) retained along with repair orders in the forklift's service history file.

Failure to comply with these requirements will void the forklift's certification.

Mast Serial #: \_\_\_\_\_ Year: \_\_\_\_\_ Model: \_\_\_\_\_  
Chassis Serial #: \_\_\_\_\_ WO: \_\_\_\_\_  
Hour Meter: \_\_\_\_\_ Certification #: \_\_\_\_\_

ENGINE		Meets Stds.	Adjust/Repair/Replace
<b>REPLACE</b>			
ITEM #			
1	Tune-up, including: Oil Engine oil filter Spark plugs Distributor cap Rotor PCV valve Ignition timing Engine performance at idle and while accelerating Engine RPM at no load and maximum load Engine valves	<input type="checkbox"/>	<input type="checkbox"/>
<b>INSPECT AND ADJUST</b>			
ITEM #			
2	Abnormal noise	<input type="checkbox"/>	<input type="checkbox"/>
3	Engine motor mount	<input type="checkbox"/>	<input type="checkbox"/>
4	Belts	<input type="checkbox"/>	<input type="checkbox"/>
<b>MEASURE</b>			
ITEM #			
5	Cylinder compression pressure -- 80% of factory specification	<input type="checkbox"/>	<input type="checkbox"/>
<b>TRANSMISSION</b>			
<b>DRAIN AND REPLENISH</b>			
ITEM #			
6	Oil filter	<input type="checkbox"/>	<input type="checkbox"/>
7	Transmission oil and differential fluid	<input type="checkbox"/>	<input type="checkbox"/>
<b>LUBRICATE</b>			
8	Universal joint	<input type="checkbox"/>	<input type="checkbox"/>
<b>INSPECT AND ADJUST</b>			
9	Transmission and differential leaks	<input type="checkbox"/>	<input type="checkbox"/>
10	Housing for damage	<input type="checkbox"/>	<input type="checkbox"/>
11	Control valve clutch	<input type="checkbox"/>	<input type="checkbox"/>
12	Inching valve	<input type="checkbox"/>	<input type="checkbox"/>
13	Output shaft	<input type="checkbox"/>	<input type="checkbox"/>
14	Axle shaft	<input type="checkbox"/>	<input type="checkbox"/>
15	Transmission oil pressure and stall RPM -- 80% of factory specification	<input type="checkbox"/>	<input type="checkbox"/>

FUEL SYSTEM		Meets Stds.	Adjust/Repair/Replace
<b>REPLACE</b>			
ITEM #			
16	Fuel filter	<input type="checkbox"/>	<input type="checkbox"/>
<b>INSPECT</b>			
ITEM #			
17	For leaks	<input type="checkbox"/>	<input type="checkbox"/>
18	Carburetor linkage	<input type="checkbox"/>	<input type="checkbox"/>
19	Water separator	<input type="checkbox"/>	<input type="checkbox"/>
20	Injection pump timing	<input type="checkbox"/>	<input type="checkbox"/>
21	LPG regulator and vaporizer	<input type="checkbox"/>	<input type="checkbox"/>
22	LPG Tank	<input type="checkbox"/>	<input type="checkbox"/>
<b>COOLING SYSTEM</b>			
<b>DRAIN, FLUSH AND REFILL</b>			
ITEM #			
23	Cooling system	<input type="checkbox"/>	<input type="checkbox"/>
<b>INSPECT AND ADJUST</b>			
ITEM #			
24	Check for leaks (pressure system) Fan clutch Water pump Fan belt	<input type="checkbox"/>	<input type="checkbox"/>
25	Fan belt	<input type="checkbox"/>	<input type="checkbox"/>
26	Fan and tensioner bearings	<input type="checkbox"/>	<input type="checkbox"/>
27	Thermostat	<input type="checkbox"/>	<input type="checkbox"/>
28	Clean screen and radiator	<input type="checkbox"/>	<input type="checkbox"/>
29	Radiator mounts	<input type="checkbox"/>	<input type="checkbox"/>
30	Radiator and radiator cap	<input type="checkbox"/>	<input type="checkbox"/>
<b>STEERING SYSTEM</b>			
<b>INSPECT, ADJUST OR ALIGN</b>			
ITEM #			
31	Steering wheel for damage or play	<input type="checkbox"/>	<input type="checkbox"/>
32	Steering valve for oil leaks and looseness	<input type="checkbox"/>	<input type="checkbox"/>
33	Wheel bearings and seals	<input type="checkbox"/>	<input type="checkbox"/>
34	King pin, tie rods, and drag links	<input type="checkbox"/>	<input type="checkbox"/>
35	Rear axle for cracks, damage, deformation	<input type="checkbox"/>	<input type="checkbox"/>
36	Steering knuckle for damage	<input type="checkbox"/>	<input type="checkbox"/>
37	Power steering cylinder for leaks	<input type="checkbox"/>	<input type="checkbox"/>
38	Mounting and linkage	<input type="checkbox"/>	<input type="checkbox"/>
39	Power steering hoses	<input type="checkbox"/>	<input type="checkbox"/>

CLEAN AND LUBRICATE		Meets Stds.	Adjust/Repair/Replace
40	Grease fittings	<input type="checkbox"/>	<input type="checkbox"/>
<b>BRAKES</b>			
ITEM #			
41	Service brake tension and play	<input type="checkbox"/>	<input type="checkbox"/>
42	Parking brake and automatic parking brake tension and play	<input type="checkbox"/>	<input type="checkbox"/>
43	Brake shoe or pad condition -- 80% of original specifications	<input type="checkbox"/>	<input type="checkbox"/>
44	Park brake lever and cable	<input type="checkbox"/>	<input type="checkbox"/>
45	Brake lines for damage and leaks	<input type="checkbox"/>	<input type="checkbox"/>
46	Brake reservoir level and leaks	<input type="checkbox"/>	<input type="checkbox"/>
47	Master cylinder and wheel cylinder for wear, damage, leaks and mounting	<input type="checkbox"/>	<input type="checkbox"/>
48	Drum and lining clearance (rotor for disk brakes)	<input type="checkbox"/>	<input type="checkbox"/>
49	Drum wear and damage	<input type="checkbox"/>	<input type="checkbox"/>
50	Anchor pin	<input type="checkbox"/>	<input type="checkbox"/>
51	Brake shoe return spring	<input type="checkbox"/>	<input type="checkbox"/>
52	Automatic adjuster	<input type="checkbox"/>	<input type="checkbox"/>
53	Backing plate	<input type="checkbox"/>	<input type="checkbox"/>
54	Seat switch (power cut off)	<input type="checkbox"/>	<input type="checkbox"/>
<b>TIRES AND WHEELS</b>			
ITEM #			
55	Tire inflation pressure	<input type="checkbox"/>	<input type="checkbox"/>
56	Tires for wear, cuts, damage -- 80% of original tread	<input type="checkbox"/>	<input type="checkbox"/>
57	Foreign matter imbedded in the tire	<input type="checkbox"/>	<input type="checkbox"/>
58	Lug, wheel and hub nuts	<input type="checkbox"/>	<input type="checkbox"/>
59	Rim, side ring and disc wheel	<input type="checkbox"/>	<input type="checkbox"/>
60	Front and rear wheel bearing	<input type="checkbox"/>	<input type="checkbox"/>
<b>MAST</b>			
ITEM #			
61	Mast rollers	<input type="checkbox"/>	<input type="checkbox"/>
62	Carriage rollers	<input type="checkbox"/>	<input type="checkbox"/>
63	Mast chains	<input type="checkbox"/>	<input type="checkbox"/>
64	Hydraulic lines	<input type="checkbox"/>	<input type="checkbox"/>
65	Mast mountings	<input type="checkbox"/>	<input type="checkbox"/>
66	Tilt mountings	<input type="checkbox"/>	<input type="checkbox"/>
67	Fork thickness -- 90% of factory specification	<input type="checkbox"/>	<input type="checkbox"/>
68	Side shifter bearings	<input type="checkbox"/>	<input type="checkbox"/>
<b>HYDRAULIC SYSTEM</b>			
ITEM #			
69	Oil filter	<input type="checkbox"/>	<input type="checkbox"/>
70	Clean strainer	<input type="checkbox"/>	<input type="checkbox"/>
71	Cylinder for damage or leaks	<input type="checkbox"/>	<input type="checkbox"/>
72	Cylinder operation	<input type="checkbox"/>	<input type="checkbox"/>
73	Cylinder mounting damage or play	<input type="checkbox"/>	<input type="checkbox"/>
74	Rod, rod screw and rod end	<input type="checkbox"/>	<input type="checkbox"/>
75	Pin and cylinder bearing	<input type="checkbox"/>	<input type="checkbox"/>

		Meets Stds.	Adjust/Repair/Replace
ITEM #			
76	Mast drift - forward/reverse (tilt)	<input type="checkbox"/>	<input type="checkbox"/>
77	Lifting and lowering speed	<input type="checkbox"/>	<input type="checkbox"/>
78	Mast lift and tilt pressure	<input type="checkbox"/>	<input type="checkbox"/>
79	Oil pump	<input type="checkbox"/>	<input type="checkbox"/>
80	Hydraulic oil tank-level and contamination	<input type="checkbox"/>	<input type="checkbox"/>
81	Tank for damage or leaks	<input type="checkbox"/>	<input type="checkbox"/>
82	Control lever operation	<input type="checkbox"/>	<input type="checkbox"/>
83	Hydraulic piping and hoses for leaks & routing	<input type="checkbox"/>	<input type="checkbox"/>
84	Hydraulic lowering valve	<input type="checkbox"/>	<input type="checkbox"/>
<b>ELECTRICAL SYSTEM</b>			
ITEM #			
85	Battery fluid level and specific gravity	<input type="checkbox"/>	<input type="checkbox"/>
86	Motors for brush and/or armature wear -- 90% of factory specification	<input type="checkbox"/>	<input type="checkbox"/>
87	Wiring harness for damage	<input type="checkbox"/>	<input type="checkbox"/>
88	Fuses	<input type="checkbox"/>	<input type="checkbox"/>
89	Alternator for charging voltage	<input type="checkbox"/>	<input type="checkbox"/>
90	Starter motor for condition of pinion gear mesh	<input type="checkbox"/>	<input type="checkbox"/>
91	Pre-heater glow plug for diesel trucks	<input type="checkbox"/>	<input type="checkbox"/>
92	Engine stop for diesel trucks	<input type="checkbox"/>	<input type="checkbox"/>
93	Battery restraint system	<input type="checkbox"/>	<input type="checkbox"/>
<b>SAFETY, CHASSIS AND ERGONOMICS</b>			
ITEM #			
94	Tighten all frame and OHG bolts	<input type="checkbox"/>	<input type="checkbox"/>
95	Frame for damage	<input type="checkbox"/>	<input type="checkbox"/>
96	Overhead guard for damage	<input type="checkbox"/>	<input type="checkbox"/>
97	Load backrest extension mounting	<input type="checkbox"/>	<input type="checkbox"/>
98	Seats -- replace or reupholster if damaged	<input type="checkbox"/>	<input type="checkbox"/>
99	Seat belts for damage or play	<input type="checkbox"/>	<input type="checkbox"/>
100	Function of instruments -- warning devices, lights, turn signals, etc.	<input type="checkbox"/>	<input type="checkbox"/>
101	Paint -- steam clean, sand, prime and repaint	<input type="checkbox"/>	<input type="checkbox"/>
102	Warning labels	<input type="checkbox"/>	<input type="checkbox"/>
103	Manuals	<input type="checkbox"/>	<input type="checkbox"/>
104	Operator safety instructions	<input type="checkbox"/>	<input type="checkbox"/>
105	Product safety and service updates	<input type="checkbox"/>	<input type="checkbox"/>
Service Manager: _____			
<b>USED FORKLIFT MANAGER FINAL ACCEPTANCE</b>			
I certify that this vehicle has passed all Certified Used Equipment standards, including final appearance repair items #105 above:			
Used Forklift Manager: _____			